


Description

Used together with the telescopic duct TLTR2 to adjust duct length. Airflow direction travels from TLTR1 towards TLTR2. The maximum extension will be marked on exterior of each TLTR1. Seal joint after assembly by using

- 1) mastic tape, or
- 2) clamp (SB/SB-1) + ORINGTR (sold separately)



Order Example



Description

Used together with the telescopic duct TLTR1 to adjust duct length. Can also be used as ordinary duct.

Ød nom	t	l_1, l_2	l_3	l_{min}	l_{max}
in	in	in	in	in	in
3	0.28	9	2.25	11.25	22
4	0.28	9	2.0	11	21.5
5	0.28	9	2.0	11	21.5
6	0.28	9	2.0	11	21.5
7	0.28	9	2.0	11	21.5
8	0.28	14	2.0	16	31.5
9	0.28	14	2.0	16	31.5
10	0.28	14	2.0	16	31.5
12	0.28	14	2.0	16	31.5
14	0.28	14	2.0	16	31.5
16	0.35	14	2.0	16	31.5
18	0.35	14	2.0	16	31.5
20	0.35	14	2.0	16	31.5

Order Example

